

---

# Schlage Keypad Lock User Guide

---

*Schlage Keypad Lock  
User Guide*

*Downloaded from  
[www.strongadvocates.com](http://www.strongadvocates.com)  
by Trevino & Hudson*

---

## INTRODUCTION TO THE SCHLAGE KEYPAD LOCK

---

When it comes to securing your home, few names carry the same level of trust and reliability as Schlage. Over the years, Schlage has built a reputation for crafting durable, innovative locking solutions that blend security with convenience. Among their most popular offerings is the Schlage keypad lock, a versatile device that allows you to unlock your door with a simple code, eliminating the need for traditional keys. Whether you are a new homeowner, a landlord managing multiple properties, or simply someone looking to upgrade your home security, understanding how to use and maintain your Schlage keypad lock is essential. This comprehensive **Schlage Keypad Lock User Guide** will walk you through everything from installation and programming to troubleshooting and advanced features. By the end of this article, you will have a thorough understanding of how to get the most out of your Schlage lock, ensuring your home remains safe and your daily routine stays seamless.

Schlage keypad locks come in various models, including the Schlage Encode, Schlage Connect, and Schlage Camelot, each with unique features but sharing a common core functionality. This guide is designed to cover the fundamental aspects that apply across most models,

while also highlighting specific differences where necessary. Whether you are a tech-savvy user or someone who prefers straightforward mechanical solutions, this article will provide clear, actionable instructions. Let us begin by exploring what comes in the box and how to prepare for installation.

---

## GETTING STARTED WITH YOUR SCHLAGE KEYPAD LOCK

---

### Unboxing and Package Contents

Before you dive into installation, take a moment to inspect the contents of your Schlage keypad lock package. Typically, you will find the following items: the keypad assembly (exterior escutcheon), the interior escutcheon, a mounting plate, a strike plate, a latch assembly, screws of various sizes, a programming code card, and a user manual. Some models may also include a backup key and batteries. It is important to verify that all components are present and undamaged. If anything is missing or broken, contact Schlage customer support before proceeding.

### Tools You Might

## Need

Installing a Schlage keypad lock is a straightforward DIY project, but having the right tools on hand will make the process smoother. You will likely need a Phillips head screwdriver, a flathead screwdriver, a tape measure, and a pencil for marking. For most installations, no drilling is required unless you are replacing a different brand of lock or installing on a new door. Check the door thickness and backset to ensure compatibility. Schlage keypad locks typically fit doors that are 1.375 to 1.75 inches thick and have a 2.375 or 2.75 inch backset.

## Understanding the Keypad Layout

The keypad on your Schlage lock is designed for intuitive use. It features numbers 0 through 9, a Schlage button (often used for confirming actions), and sometimes a lock/unlock icon. The keypad is backlit for visibility at night, and it provides audible feedback to confirm button presses. Familiarize yourself with the layout before programming, as it will help you navigate the menus more confidently.

---

### STEP-BY-STEP INSTALLATION GUIDE

---

## Removing Your

## Old Lock

Start by removing your existing lock. This usually involves unscrewing the interior knob or lever, pulling off the exterior escutcheon, and removing the latch assembly. Keep the screws in a safe place, as you may need them for temporary purposes. If your old lock is a different brand, the holes in the door should still align with the Schlage template.

## Installing the Latch and Strike Plate

Insert the latch assembly into the edge of the door, ensuring the beveled side faces the door frame. Secure it with the provided screws. Next, align the strike plate on the door frame so that the latch bolt fits snugly into the hole. Screw the strike plate into place. This step is crucial for the lock to function properly, so double-check the alignment before moving on.

## Mounting the Keypad Assembly

Take the exterior keypad assembly and feed the cable through the hole in the door. Place the keypad against the door, making sure it is level. From the interior side, attach the mounting plate over the cable and secure it with the screws provided. The keypad should feel firmly

attached without any wobble.

## Connecting the Interior Escutcheon

Connect the cable from the keypad to the interior escutcheon. This is a delicate step, so handle the connector gently. Tuck any excess cable into the door cavity, then align the interior escutcheon with the mounting plate. Secure it with the screws, and then install the batteries. Most Schlage keypad locks use four AA batteries, which are included with the lock. Once the batteries are inserted, the keypad will light up and emit a beep, indicating that the lock is powered on.

## Testing the Mechanical Function

Before programming, test the mechanical function of the lock. Use the thumb turn on the interior side to lock and unlock the door. The latch should move smoothly without binding. If it sticks, adjust the strike plate or latch position. Once the mechanical operation is satisfactory, you are ready to program your lock.

---

### **PROGRAMMING YOUR SCHLAGE KEYPAD LOCK**

---

## Setting the Master Code

The master code is the most important code for your Schlage keypad lock. It allows you to add and delete user codes, change settings, and perform factory resets. By default, the master code is usually set to a factory default, such as 1234 or 0000. You should change this immediately after installation. To set the master code, press the Schlage button, then enter the current master code (the default), then press the Schlage button again. Follow the prompts on the lock to enter a new 4-8 digit master code. Confirm the code by entering it a second time. The lock will beep to confirm the change.

## Adding User Codes

User codes are the codes that family members, guests, or service providers can use to unlock the door. To add a user code, press the Schlage button, enter your master code, and press the Schlage button again. Then press the number corresponding to the user slot you want to assign (for example, 1 for the first user). Enter a new 4-8 digit code for that user, and confirm it by entering it again. The lock will beep to confirm. Repeat this process for each user you want to add. Most Schlage keypad locks support between 10 and 30 user codes, depending on the model.

## Deleting User Codes

To delete a specific user code, follow the same steps as adding a code, but when prompted to enter a new code, simply press the Schlage button without entering a code. This will clear the user slot. Alternatively, you can perform a factory reset to delete all codes at once, but that will also erase the master code.

## Changing Settings

Schlage keypad locks offer several customizable settings, such as the duration of the keypad backlight, the volume of the beep, and whether the lock automatically re-locks after a set time. To access these settings, press the Schlage button, enter your master code, and then press the 9 key. Use the keypad to navigate through the options and adjust them to your preference. Refer to your specific model's user manual for a full list of settings, as they can vary.

---

### **USING THE SCHLAGE KEYPAD LOCK DAILY**

---

## Unlocking with a Code

To unlock the door, simply enter your code on the keypad and press the Schlage button. The lock will beep and the bolt will retract, allowing you to open the door. If you enter the wrong code, the lock will flash red and beep to

indicate an error. After several incorrect attempts, the lock may temporarily disable the keypad to prevent tampering. This is a useful security feature.

## Locking from the Outside

To lock the door from the outside, press the Schlage button once without entering a code. The bolt will extend, locking the door. Some models also support one-touch locking, where you simply press the Schlage button for a second or two. This function is convenient when you are in a hurry.

## Locking from the Inside

From the inside, use the thumb turn to lock or unlock the door manually. Some models also have a button on the interior escutcheon that allows you to lock the door electronically. Using the thumb turn is recommended for everyday use, as it is the most reliable and does not drain the batteries.

## Using the Backup Key

In the event that the batteries die or you forget your code, you can always use the backup key to unlock the door. The backup key cylinder is usually located on the exterior keypad assembly. Insert the key and turn it to retract the bolt. Keep a spare key in a safe place, such as your car or a neighbor's house, so you always

have a fallback option.

---

## TROUBLESHOOTING COMMON ISSUES

---

### Keypad Not Lighting Up

If the keypad does not light up when you press a button, the most likely cause is dead batteries. Replace all four AA batteries with fresh ones. If the keypad still does not light up, check the cable connection between the keypad and the interior escutcheon. A loose or damaged cable can cause power issues. If the problem persists, contact Schlage support.

### Lock Not Responding to Codes

If you enter a code and nothing happens, try re-entering the code slowly and deliberately. The keypad may not register fast keystrokes. If that does not work, you may have accidentally changed the master code or user codes. Perform a factory reset to restore the lock to its default settings. To reset, remove the batteries, press and hold the Schlage button while reinstalling the batteries, and follow the prompts. This will erase all codes and settings.

### Bolt Sticking or

## Binding

A sticking bolt is usually caused by misalignment between the latch and the strike plate. Check the alignment and adjust the strike plate if necessary. You can use a file to enlarge the strike plate hole slightly. Lubricating the latch mechanism with a dry graphite lubricant can also help. Avoid using oil-based lubricants, as they can attract dust and cause more problems over time.

### Keypad Beeps but Bolt Does Not Move

This issue often indicates a mechanical obstruction or a weak battery. Ensure that nothing is blocking the bolt, such as debris or a misaligned door. Try manually locking and unlocking with the thumb turn to see if the mechanism operates smoothly. If the bolt moves by hand but not with the keypad, the motor may be failing. In this case, contact Schlage for a replacement.

---

## MAINTENANCE AND CARE TIPS

---

### Battery Replacement

Schlage keypad locks typically provide a low-battery warning by emitting a series of beeps when you use the keypad. Replace the batteries as soon as you hear this warning to avoid being locked out. Use high-quality alkaline batteries for the best performance. The battery life varies depending on usage, but most

users replace them once a year.

## Cleaning the Keypad

To keep the keypad looking and functioning well, clean it regularly with a soft, damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as they can damage the keypad's surface and electronics. If the keypad becomes sticky due to residue, use a mild soap solution and dry it thoroughly.

## Checking for Loose Screws

Over time, the screws on your Schlage keypad lock may loosen due to vibrations and daily use. Periodically check all screws, especially those on the mounting plate and interior escutcheon, and tighten them as needed. A loose lock can affect the alignment of the bolt and lead to sticking.

## Winter Care

In cold climates, moisture can freeze on the keypad or inside the latch mechanism. If you live in an area with harsh winters, consider using a weatherproof cover for the keypad. You can also apply a silicone-based lubricant to the latch to prevent freezing. Avoid using water to clean the lock in