
5th Wheel Towing Guide

*5th Wheel Towing
Guide*

*Downloaded from
www.strongadvocates.com
by Aydin & English*

UNDERSTANDING THE ESSENTIALS OF A 5TH WHEEL TOWING GUIDE

Embarking on a journey with a fifth wheel trailer represents a significant step up in the world of recreational travel. Unlike conventional bumper-pull trailers, fifth wheels offer superior stability, increased living space, and a towing experience that many seasoned travelers prefer. However, mastering the art of towing a fifth wheel requires a thorough understanding of the equipment, physics, and safety protocols involved. This comprehensive 5th Wheel Towing Guide will walk you through everything you need to know, from selecting the right truck to maneuvering your rig with confidence.

What Makes Fifth Wheel Towing Different?

The fundamental difference between a fifth wheel and a travel trailer lies in how the weight is distributed. A fifth wheel hitch sits in the bed of a pickup truck, connecting to a kingpin on the trailer. This design places the pivot point directly over the rear axle of the towing vehicle, distributing weight more evenly across the truck's chassis. This configuration provides a lower center of

gravity and significantly reduces sway compared to bumper-pull trailers, making for a more controlled and stable towing experience.

Another key distinction is the turning radius. Because the hitch is located in the truck bed, a fifth wheel can turn much tighter than a travel trailer. This is particularly advantageous when navigating campgrounds, gas stations, or tight mountain roads. However, it also demands awareness of the truck bed clearance to avoid contact between the trailer and the cab during sharp turns.

Selecting the Right Tow Vehicle

Before you can even think about hitching up, you must ensure your truck is up to the task. The single most critical factor in fifth wheel towing is payload capacity, not towing capacity. Many trucks can pull massive loads, but they lack the payload to handle the pin weight of a fifth wheel. Pin weight is the portion of the trailer's weight that presses down on the hitch in the truck bed, typically ranging from 15% to 25% of the trailer's total weight.

To determine if your truck is suitable, follow these steps:

- Locate the payload capacity sticker on your driver's side door jamb. This number represents the

maximum weight your truck can carry, including passengers, cargo, the hitch itself, and the trailer's pin weight.

- Weigh your fully loaded truck at a public scale to get an accurate baseline.
- Subtract the weight of all passengers, gear, and the hitch from the payload capacity. The remaining figure is your available pin weight allowance.
- Choose a fifth wheel whose expected pin weight falls within that allowance.

For most larger fifth wheels, a heavy-duty truck is essential. The half-ton segment has made strides with models like the Ford F-150, Ram 1500, and Chevrolet Silverado 1500, but these are generally limited to smaller, lighter fifth wheels. For anything over 8,000 pounds, a three-quarter-ton or one-ton truck is the safer and more practical choice. Diesel engines are highly preferred for their torque, exhaust braking capabilities, and fuel economy under load.

Choosing the Right Fifth Wheel Hitch

The hitch is the critical link between your truck and trailer. Several types of fifth wheel hitches are available, each with its own advantages:

- **Fixed Hitches:** These are simple, reliable, and generally the most affordable. They sit in the truck bed and cannot be moved without unbolting them. They offer a solid

connection but take up significant bed space.

- **Sliding Hitches:** For trucks with short beds (typically less than 6.5 feet), a sliding hitch is essential. It allows the hitch to slide rearward on a track during sharp turns, preventing the trailer from contacting the truck cab. This mechanism can be manual or automatic.
- **Puck System Hitches:** Many modern trucks come pre-drilled with a puck system in the bed. These hitches drop directly into the pucks, offering a clean, low-profile installation with excellent stability. They are becoming the industry standard for heavy-duty trucks.
- **Gooseball to Fifth Wheel Adapters:** Some truck owners prefer a gooseneck ball for a completely flat bed. Adapters are available to convert a gooseneck ball into a fifth wheel connection, though purists often find these less stable than a true fifth wheel hitch.

When selecting a hitch, consider weight capacity first. Always choose a hitch rated for at least as much as your trailer's GVWR (Gross Vehicle Weight Rating). Pay attention to jaw mechanisms as well. Double jaw designs securely grip the kingpin from two sides, reducing chucking and movement at the connection point.

Hitching Up

Properly: A Step-by-Step Process

Connecting a fifth wheel trailer incorrectly can lead to a catastrophic separation. Follow this procedure every single time to ensure a secure connection:

1. Back your truck toward the trailer so the kingpin is positioned directly under the hitch head. Ideally, aim for the kingpin to be slightly forward of center in the hitch.
2. Lower the landing gear until the kingpin is slightly below the hitch jaw level. This allows the trailer to ride up slightly as you connect, ensuring solid engagement.
3. Engage the trailer brakes via the breakaway switch or a manual brake controller override.
4. Slowly back the truck until the kingpin fully engages the hitch. You should hear a solid clunk as the jaws close around the pin.
5. Test the connection by pulling forward gently with the trailer brakes still engaged. The truck should move forward, and the trailer should not detach.
6. Verify the hitch handle is in the locked position and insert the safety pin or lock.
7. Attach the safety chains, crossing them underneath the gooseneck or kingpin area. These provide a backup connection in case the hitch fails.
8. Connect the breakaway switch cable to the truck. This is a vital safety device that applies the trailer brakes if it separates from

the tow vehicle.

9. Connect the electrical umbilical cord and verify all lights and signals are working.
10. Raise the landing gear completely and perform a final walk-around inspection.

Weight Distribution and Setup

Proper weight distribution is paramount for safe fifth wheel towing. An improperly loaded trailer can lead to instability, poor handling, and excessive wear on tires and suspension. The goal is to achieve a balanced load where the pin weight is between 15% and 25% of the total trailer weight, with the majority of the remaining weight centered over the trailer axles.

Load heavier items such as tools, water (if traveling), and camping gear directly over the trailer axles. Avoid placing excessive weight at the rear of the trailer, as this can cause dangerous sway. Inside the truck bed, keep items low and secured. Heavy cargo placed high in the bed can negatively affect the truck's center of gravity and handling.

Once loaded, take your rig to a public scale. Weigh each axle individually. The front axle of the truck should not be too light, as this reduces steering control. Ideally, the front axle of the loaded truck should weigh close to its unloaded weight plus the weight of passengers. If it is significantly lighter, you may need to adjust your loading or consider air bags or helper springs to level the truck.

Driving Techniques for Fifth Wheel Towing

Driving a fifth wheel rig demands a different mindset than daily commuting. Here are essential techniques to master:

- **Acceleration and Braking:** Accelerate gently and smoothly. Anticipate stops far in advance and brake early. Engine braking (using the transmission to slow down) is your best friend on descents. Modern diesel trucks with exhaust brakes make descending steep grades manageable and safe.
- **Turning:** Remember that the rear of the trailer cuts in sharply during turns. Swing wide to the right before turning left, and vice versa. Use your mirrors constantly to monitor the position of the trailer relative to curbs, signs, and other obstacles.
- **Lane Changes:** Signal well in advance and check your mirrors thoroughly. The length of your rig means you need more space to complete a lane change. Avoid sudden movements.
- **Backing Up:** This is arguably the most challenging skill. Practice in an empty parking lot before tackling a campground. The golden rule is to put your hand at the bottom of the steering wheel and move it in the direction you want the trailer to go. Small,

gentle inputs are far more effective than large steering corrections.

- **Pulling into Gas Stations:** Look for truck stops or stations with easy access and open layouts. Avoid stations with low canopies, tight corners, or inadequate space to navigate.

Essential Safety Checks Before Each Trip

A pre-trip inspection should become a ritual before every journey. This 5th Wheel Towing Guide recommends the following checklist:

- Inspect tire pressure and condition on both truck and trailer. Under-inflated tires generate excessive heat and can fail catastrophically.
- Check all lights and turn signals.
- Verify the hitch is securely locked and the safety pin is in place.
- Ensure safety chains are properly crossed and secured.
- Test the breakaway switch battery and connection.
- Inspect the kingpin and hitch head for wear or damage.
- Check the landing gear for proper operation and ensure it is fully raised.
- Verify the trailer brakes are functioning by testing them with the manual brake controller.
- Check all cargo doors, windows, and vents to ensure they are closed and secured.

Understanding Trailer Brakes and Controllers

Fifth wheel trailers are heavy, and your truck's brakes alone are not sufficient to stop the combined mass safely. Trailer brakes are mandatory on all but the smallest trailers. Modern brake controllers are sophisticated devices that synchronize the trailer brakes with the tow vehicle's braking system.

Proportional brake controllers are the standard today. They apply the trailer brakes in proportion to how hard you are stopping the truck. This provides smooth, natural braking that is far superior to older time-delay controllers. Many modern trucks have integrated brake controllers built into the dashboard, which communicate directly with the trailer via the factory wiring harness.

Adjusting the brake controller gain is important. The goal is to apply enough trailer braking power to assist the truck without causing the trailer to drag or lock up. A common method is to drive on a dry, level road at around 25 mph and manually activate the trailer brakes. If the trailer brakes are set correctly, you should feel a firm, controlled stop without the truck dragging the trailer.

Maintaining Your Fifth Wheel

Setup

Regular maintenance extends the life of your equipment and keeps you safe on the road. Lubricate the hitch jaws, kingpin, and all moving parts according to the manufacturer's schedule. Inspect the trailer frame, suspension, and axle components for cracks or corrosion. Keep the electrical connections clean and free of corrosion. Service the trailer brakes annually, including inspecting brake shoes, magnets, and wiring.

Tires deserve special attention. RV tires often age out before they wear out. Replace trailer tires every five to seven years, regardless of tread depth. Always carry a spare tire and the tools necessary to change it, as roadside assistance on a fifth wheel can be expensive and slow.

Common Mistakes to Avoid

Even experienced towers can fall into bad habits. Here are the most common mistakes to avoid according to this 5th Wheel Towing Guide:

- Overloading the truck's payload capacity. This is the number one mistake and the most dangerous.
- Ignoring tire pressure. Under-inflated tires on a heavy rig are a recipe for blowouts.
- Neglecting to test the breakaway switch. A dead battery means no emergency braking.
- Forgetting to raise the landing gear fully. Dragging it can damage

the gear and the road.

- Towing with the fresh water tank full. Water weighs over eight pounds per gallon, adding significant weight.
- Making sudden steering or braking inputs on slippery roads.
- Failing to account for the rig's height at low clearances.

Parking and Campground Arrival

Arriving at your campsite should be a calm, planned process. If possible, scout

the site before attempting to park. Look for obstacles like trees, rocks, and uneven ground. Use a spotter with clear hand signals or a two-way radio. Pull through sites are ideal if available, as they eliminate the need to back up. If you must back in, take your time and make small corrections. There is no shame in pulling forward to reset your approach if it does not look right.

Once parked, level the trailer side-to-side using leveling blocks under the tires, then front-to-back using the landing gear. Lower the stabilizer jacks to reduce movement inside the trailer. Connect to shore power and ensure the electrical polarity is correct before plugging in your appliances.

CONCLUSION
